THE FOLLOWING INSTRUCTIONS ARE NOT INTENDED TO BE A STEP BY STEP INSTALLATION CHECKLIST. IT IS ASSUMED THE INSTALLER HAS GENERAL CONSTRUCTION KNOWLEDGE. WINROC-SPI ASSUMES RESPONSIBILITY FOR INSTALLATION ACTIONS TAKEN OR NOT TAKEN AND IS NOT RESPONSIBLE FOR INSTALLER SELECTION.

DO NOT INSTALL PRODUCT OF UNACCEPTABLE QUALITY. CONTACT YOUR AREA WINROC-SPI REPRESENTATIVE IMMEDIATELY. WE WILL NOT BE RESPONSIBLE FOR INSTALLATION OR REMOVAL COSTS OF UNACCEPTABLE PRODUCT.

## WALL MOUNTED BARREL AND PYRAMIDAL DIFFUSERS

## INSTALLATION INSTRUCTIONS

- 1.USING THE 6" L-CLIPS AS A TEMPLATE, DRILL 1/8" POP-RIVET HOLES IN THE FRONT, TOP EDGE OF THE DIFFUSER. HOLES SHOULD BE DRILLED FROM THE FINSHED SIDE AND LOCATED SO THE CLIP FACE IS FLUSH WITH THE DIFFUSER EDGE.
- 2. DRILL 1/8" POP-RIVET HOLES FOR HOOK & LOOP BRACKET IN SIMILAR MANNER. (DIAGRAMS INDICATE LOCATIONS)
- 3. INSTALL L-CLIPS AT TOP OF DIFFUSER AND HOOK & LOOP BRACKETS AT THE OF DIFFUSER BOTTOM WITH WHITE-HEAD POP-RIVETS. INSTALL POP-RIVET FROM FINISH SIDE.
- 4. MOUNT 6" WALL BAR TO WALL STRUCTURE USING APPROPRIATE FASTENERS. TOP OF WALL BAR SHOULD BE LOCATED 1/8" BELOW DESIRED HEIGHT OF DIFFUSER. ALLOW A 1" MINIMUM CLEARANCE ABOVE TOP OF WALL BAR TO ENGAGE L-CLIP ON WALL BAR.
- 5. PEEL OFF RELEASE BACKER OF HOOK & LOOP TO EXPOSE ADHESIVE AND INSERT L-CLIPS ONTO WALL BRACKETS. WITH L-CLIPS ENGAGED, LEVEL AND ADJUST POSITION. PRESS BOTTOM OF DIFFUSER TO WALL TO ADHERE HOOK & LOOP BRACKET.



